



JAMES THOMAS ENGINEERING, INC.
10240 Caneel Drive, Knoxville, Tennessee 37931 USA.
TEL. (865) 692-3060 FAX. (865) 692-9020

Lamp Replacement instructions for the D3641-ETL

Note: (tools needed; Flat head type screwdriver)

1. Disconnect Power before relamping. Relamping is done from the front of the Unit.
2. Remove the 4 screws holding the Safety screen in place.
3. Pull up on retaining ring clips and slide away from the lamp in the direction of the slot .
4. Remove chrome bulb retaining ring and lamp.
5. Notice and remove the ring terminals on the back of the lamp with a screwdriver.
6. Replace Lamp type Par36 DWE 120volt 650 watt max. and reverse steps above.

If you have any questions please contact us at the numbers above.

Circuit # 1

Circuit # 2

